

**PRATICAL ADVICE FOR THE CORRECT USE OF "CRISTAL MIX" BY
ADDITIVATION IN TRUCK MIXER ON SITE**

1.

AFTER THE INTRODUCING OF "CRISTAL MIX" IN THE TRUCK MIXER, LET THE OPERATOR RINSE THE LOADING HOPPER AND THE FIRST BLADES OF THE DRUM USING VERY LITTLE WATER;



2.

AFTER THE INTODUCTION OF "CRISTAL MIX" IN THE TRUCK MIXER, MIX FOR 1 MINUTE FOR EACH OF CU.M OF CONCRETE CONTAINED IN THE MACHINE AT MEDIUM/HIGH SPEED.



3.

DO NOT ADD WATER TO THE CONCRETE MIXTURE ADTER INTRODUCING "CRISTAL MIX" IN THE CEMENT MIXER, EXCEPT AS PROVIDED IN POINT 1).



4.

AT THE CONSTRUCTION SITE GET FROM THE BATCHING PLANT AN ADEQUATE QUANTITY OF THE FLUIDIFIER USED BY THEM IN ORDER TO BE ABLE TO CORRECT, IN EXTREME CASES, THE CONCRETE MIX AFTER THE ADDITION OF "CRISTAL MIX".

