

## PRATICAL ADVICE FOR THE CORRECT USE OF “CRISTAL MIX” BY ADDITIVATION IN A CONCRETE MIXING PLANT



### SEQUENCE OF PROCESSES

1. Placement of the truck mixer in the loading point/tunnel
2. Handing of the barrel in unloading to allow any residual cement water to escape from the previous load
3. Locanding of the concrete in the truck mixer
4. Mixing of the concrete according to the standard
5. Addition of Cristal Mix in the agreed percentage
6. Mixing of concrete (at least 1 min/cu.m.) at medium/high speed
7. Removing of the truck mixer from the loading point/tunnel

All information is given in good faith and without any warranty. The application, use and processing of these products are beyond our control and therefor your responsibility. Any eventual established liability, through bad application or any other reason, for any damages, is always limited to the values of the goods supplied by System Technology. The products and systems are manufactured under total quality management.